PRIMUS 45 HANDPIECE

OWNER'S MANUAL



® RAM PRODUCTS, INC.®

182 Ridge Road, Suite D, Dayton, N.J 08810

732.651.5500



732.651.6688





CONTENTS

BASIC SAFETY AND PRECAUTIONS ...1
INSTRUCTIONS FOR CHANGING TOOL ...1
INSTRUCTIONS FOR CHANGING COLLET ...2
CHUCKS
INSTRUCTIONS FOR CHANGING BRUSHES ...2
SUGGESTED MAINTENANCE AND TIPS ...3
SCHEMATIC DIAGRAM ...3
PARTS LIST FOR HANDPIECE ...4

A. BASIC SAFETY AND PRECAUTIONS

- When using electric tools, use basic safety precautions in order to reduce risk of fire, electric shock, and personal injury.
- 2. Do not expose electric tools to water, or use in damp or wet locations.
- Do not wear loose clothing or jewelry and secure long hair as they can be caught in the drill.
- Wear protective eyewear, wear proper clothes for working with dust, always hold the handpiece securely, hold the handpiece while in operation with the power on.
- 5. Do not leave the equipment rotating on table or floor.
- 6. Keep away from children.


Warning: NEVER TURN SET RING WHILE MOTOR IS ROTATING. PERMANENT DAMAGE TO THE MOTOR IS POSSIBLE.



B. INSTRUCTIONS FOR CHANGING TOOL

Originally, $\varnothing 2.34$ mm Blank Bur is mounted. Please use only the tools with $\varnothing 2.34$ mm shank which have been authorized.

- While holding the handpiece, turn the Set Ring fully toward (R) direction. Take out the Blank Bur and put the tool into the bottom Collet.
- Turn the Set Ring to (S) direction, to secure your tool.
- Spin the tool by fingers to confirm that th tool is securely fixed. Be careful with the blade (edge) of tool not to hurt the fingers.




C. INSTRUCTIONS FOR CHANGING COLLET CHUCKS


Originally, φ 2.34mm Collet is mounted. It is possible to replace with other sizes of Collets according to demand. When replacing the Collet, insert the Blank Bur or tool and loosen or tighten the Collet using the wrench which has been supplied.

While holding the handpiece, turn the Set Ring fully toward (R) direction. Be sure that the Blank Bur is inside of Collet. Place the Wrench on the Collet, and turn it toward the direction of "loosen". If the Collet slips and impossible to loosen, try to hit the Wrench by Hammer at an instance, and remove the Collet. Be careful not to hit your fingers.

Turn fully Set Ring to "R" direction and loosen and remove Collet by Wrench.




- Place the other Collet and turn the Collet toward the direction of "tighten". Make sure to secure the collet firmly.
- 3. Take the Wrench out and turn the Set Ring back toward (S) direction.
- Spin the tool by fingers to confirm that the tool is securely fixed. Be careful with the blade (edge) of tool not to hurt the fingers.



D. INSTRUCTIONS FOR CHANGING BRUSHES

When Carbon Brush is worn out, the Handpiece rotates unstably or stops. Please replace the Carbon Brush, we recommend to replace both sides of the Carbon Brush at the same time.

- Turn the Motor Cap to the left and remove it.
- Using Phillips Screw Driver, remove the screw that is securing the Carbon Brush. Be careful not to loose the screw.
- Take the worn out Carbon Brush out, and replace with a new one and secure it by screw.
- 4. Turn the Motor Cap to the right to fit onto the Handpiece.



E. SUGGESTED MAINTENANCE AND TIPS


- Open, inspect and test each item although we do test carefully prior to shipments. Upon receiving repaired items, to check or test as well.
- All brush handpieces include a wrench tool which if needed can be used to remove the collet chuck for replacement or cleaning. All brush handpieces come with a spare set of 2 replacement carbon brushes.
 This is a normal wearing part and estimated at 1,000hrs.

3-2022 issue 1

Perhaps change/replace every year or inspect once a year for wear. It is suggested to tape these to the bottom of the controller and date it. For the laboratory, it is easier and only a few minutes to replace and maintain once a year as a minimal low cost maintenance. In the operatory area, every 2-3 years should be adequate.

- Never use chemicals for cleaning as often they are harsh and can corrode parts. Use only isopropyl alcohol in either sealed wipes or with a tissue to clean the exterior and any dust or debris that has accumulated.
- Use good quality burs. Do not force any burs into the chuck, make sure burs are not eccentric. If any rust on the bur shaft, it is best to discard. Always leave a bur securely locked in the handpiece. Wait for the handpiece to stop spinning before changing burs.
- 5. After sterilization of burs make sure they are completely dry and avoid getting chemicals / disinfectants inside the handpiece.
- Electric lab handpieces have grease sealed ball bearings. Please do not oil as you would air or high-speed handpieces as this would break down the grease sealed bearings.
- For cleaning, it is suggested once a week to use a can of compressed air often sold at office supply, computer supply stores. (The compressed air at the bench is high pressure and can not only push any dust or dirt inside further but also can upset the small balls that are part of the bearings which are the life line of the handpiece.

PARTS LIST FOR FOR PRIMUS 45 HANDPIECE



1 HAND CAP COVER 36 SNAP RING 2 HAND CAP HEAD 37 1030 FIX O-RING 3 CHUCK HOUSING C-RING 38 MOTOR CASE 39 MOTOR CASE BOLT 4 1370 WAVE WASHER 40 SM110 MAGNET C 5 COLLAR 41 SM110 MAGNET GUIDE 6 BEARING FIX WASHER 42 COPPER WASHER 7 1370 WASHER 43 1030 WAVE WASHER
3 CHUCK HOUSING C-RING 38 MOTOR CASE 4 1370 WAVE WASHER 40 SM110 MAGNET C 5 COLLAR 41 SM110 MAGNET GUIDE 6 BEARING FIX WASHER 42 COPPER WASHER
3 RING 39 MOTOR CASE BOLT 4 1370 WAVE WASHER 40 SM110 MAGNET C 5 COLLAR 41 SM110 MAGNET GUIDE 6 BEARING FIX WASHER 42 COPPER WASHER
4 1370 WAVE WASHER 40 SM110 MAGNET C 5 COLLAR 41 SM110 MAGNET GUIDE 6 BEARING FIX WASHER 42 COPPER WASHER
5 COLLAR 41 SM110 MAGNET GUIDE 6 BEARING FIX WASHER 42 COPPER WASHER
6 BEARING FIX WASHER 42 COPPER WASHER
7 1370 WASHER 43 1030 WAVE WASHER
8 BALL BEARING(1370ZZ) 44 BALL BEARING(1040ZZ)
9 HAND CAP BODY 45 1040 COPPER WASHER
10 BUSH 46 1040 TEFLON WASHER
11 BALL BEARING(1480ZZ) 47 1040 SPACER
12 1480 WASHER 48 SHAFT Ø4
13 1480 WAVE WASHER 49 CORE
14 TEST BUR 50 FRONT SHAFT BUSH Ø4
15 COLLET CHUCK 2.35 51 COMMUTATOR
16 CHUCK HOUSING 52 COIL
17 CHUCK SPRING 53 WEDGE
18 JOINT SHAFT BODY 54 FAN
19 JOINT SHAFT 55 830 SPACER
20 JOINT SHAFT FIX PIN 56 TEFLON WASHER
21 BH60 O-RING 57 BEARING HOUSING
BEARING BUSH COLLAR 58 BACK BEARING SIT
WASHER 59 BRUSH HOLDER
23 BEARING BUSH COLLAR 60 CARBON BRUSH
24 BH60 CONNECTOR 61 CARBON BRUSH
25 SET RING WASHER SPRING
26 SET RING TEFLON 62 CARBON BRUSH CAP
WASHER 63 TERMINAL (L)
27 SET RING 64 TERMINAL (R)
28 SET RING INSERT 65 CARBON BRUSH BOLT
29 CAM TEFLON WASHER 66 BALL BEARING 1030ZZ
30 CAM 67 BR BRUSH BOLT
31 CAM BALL 68 MOTOR CORD
32 M2.5 CARBON HOUSING
33 MOVING HOUSING COVER SPRING PRIMIS 45 SPINDLE
34 MOVING HOUSING 70 ASSEMBLY
35 MOTOR CASE COVER 71 ARMATURE ASSEMBLY

WARRANTY PERIOD

Warranty is valid within the United States only.

HANDPIECES — These products are under warranty for a period of SIX MONTHS from the date of original installation by the purchaser. IT DOES NOT COVER MISUSE, NORMAL BEARING, OR CARBON BRUSH WEAR.

IN HOUSE OR FACTORY REPAIR - WARRANTY CLAIMS —

Please visit our website, www.ramprodinc.com, to download the Customer Service Request Form located at the top right of the website page. For warranty claims, please include a copy of your invoice or reference purchase date. Repairs carry a 90 day warranty.

We maintain parts for Ram and many other similar models to perform service. When sending items for service please pack it well with proper protection. It is your responsibility to get the unit to us. Return shipping and handling is covered by Ram Products, Inc.

PRODUCT WARRANTY

All returned items shall be free from defects/alterations in material workmanship and original product design.

- The product shall have been used under the conditions for which it has been intended, and in a manner for which it has been designed.
- The product shall have been operated in a manner for which it was intended and in the proper environmental conditions.
- The customer must maintain the product as specified within the individual product instruction booklet.

Electrical and mechanical equipments which are mishandled, used incorrectly, and/or used for a purpose other than that for which they were designed and intended, will void the product warranty.

WARRANTY CLAIMS

Should your product require service within the warranty period, we will elect to make the necessary repair or replacement at no charge including return shipping. It is your responsibility to return the product to Ram Products and it is recommended that returns have tracking information and to be adequately insured against carrier loss or damage.

All claims should describe the specific problem for accurate analysis and evaluation, the return date of the warranty card along with the supply house and/or dealer name.

WARRANTY REGISTRATION

In order to validate your warranty, the form must be filled out completely on the website: www.ramprodinc.com/warranty within 10 days of purchase/installation.



🕒 1-732-651-5500 🌘 www.ramhp.com

